


M18BLTS-551 BL TELESCOPING SHEAR IN2

4933480866 - M18BLTS-551 - 4000503305





Position	Quantity	Description	Part number	EAN
0001 1	15	SCREW	4931453124	4002395152780
0002 2	2	SCREW	4931436686	4002395258260
0005 3	1	RUBBER RING	4931496738	4058546538750
0015 4	1	SCREW	4931466683	4058546279004
0016 5	2	SCREW	4931466797	4058546280147
0020 6	5	SCREW	4931466677	4058546278946
0021 7	1	PIPE CLAMP	4931496739	4058546538767
0026 8	1	SPRING	4931454803	4058546014209
0047 9	1	WASHER	4931511208	4058546650643
0048 10	1	NUT	4931511209	4058546650650
0050 11	1	SCREW	4931511210	4058546650667
0051 12	1	WASHER	4931511211	4058546650674
0052 13	1	BOLT	4931511212	4058546650681
0055 14	1	COVER	4931496740	4058546538774
0067 15	1	WRENCH	4931511213	4058546650698
0078 16	1	SPRING	4931454808	4058546014254
0079 17	1	TRIGGER	4931496741	4058546538781
0102 18	1	STRAP	4931496742	4058546538798
0104 19	1	RUBBER BUFFER	4931496743	4058546538804
0105 20	1	RUBBER BUFFER	4931496744	4058546538811
0106 21	1	RUBBER BUFFER	4931496745	4058546538828
0120 22	1	RATING PLATE	4931496746	4058546538835
0121 23	1	HOUSING	4931496747	4058546538842
0122 24	1	TRIGGER	4931496240	4058546533779
0124 25	1	MOTOR ASSEMBLY	4931496748	4058546538859
0125 26	1	GEAR BOX	4931496749	4058546538866
0126 27	1	DRIVING SHAFT	4931496750	4058546538873
0127 28	1	COLLAR	4931496751	4058546538880
0128 29	1	CONNECTOR	4931496752	4058546538897
0129 30	1	CUTTING HEAD	4931496753	4058546538903
0130 31	1	HOOK	4931496754	4058546538910
0131 32	1	SHEAR BLADE	4931496755	4058546538927
0132 33	1	Repl. Blade for M18 BL Telescopic Shear	4932493557	4058546484286
0133 34	1	HOLDING BRACKET	4931496246	4058546533830