



M18ABL-0 AREA BOOM LIGHT XXX

4933498147 - M18ABL-0 - 4000503425





Position	Quantity	Description	Part number	EAN
0006 1	1	SCREW	4931506308	4058546556228
0007 2	1	PRINTED CIRC. BOARD	4931506309	4058546556235
0008 3	1	SCREW	4931506310	4058546556242
0009 4	1	ELECTRONIC	4931506311	4058546556259
0013 5	1	SCREW	4931506312	4058546556266
0018 6	1	HINGE PIECE	4931506313	4058546556273
0021 7	1	HINGE PIECE	4931506314	4058546556280
0022 8	1	WIRE	4931506315	4058546556297
0024 9	1	SCREW	4931506316	4058546556303
0026 10	1	HINGE PIECE	4931506317	4058546556310
0027 11	1	PLATE	4931506318	4058546556327
0028 12	1	HOUSING	4931506319	4058546556334
0030 13	1	BUTTON	4931506320	4058546556341
0033 14	1	GASKET	4931506321	4058546556358
0034 15	1	COVER	4931506322	4058546556365
0035 16	1	SUPPORTING PLATE	4931506323	4058546556372
0036 17	1	SUPPORTING PLATE	4931506324	4058546556389
0037 18	1	BUSHING	4931506325	4058546556396
0040 19	1	SCREW	4931506326	4058546556402
0043 20	1	SHAFT	4931506327	4058546556419
0044 21	1	ROCKER BAR	4931506328	4058546556426
0045 22	1	ROCKER BAR	4931506329	4058546556433
0046 23	1	BLOCK	4931506330	4058546556440
0052 24	1	HOUSING	4931506331	4058546556457
0053 25	1	SCREW	4931506332	4058546556464
0054 26	1	COVER	4931506333	4058546556471
0055 27	1	RATING PLATE	4931506334	4058546556488
0070 28	1	ASSEMBLY KIT	4931506335	4058546556495
0071 29	4	COVER	4931506336	4058546556501
0072 30	1	HOUSING	4931506337	4058546556518
0073 31	1	COVER	4931506338	4058546556525
0074 32	1	HOUSING	4931506339	4058546556532
0075 33	1	ELECTRONIC	4931506340	4058546556549
0076 34	1	SHAFT	4931506341	4058546556556
0077 35	1	COVER	4931506342	4058546556563
0078 36	1	SHAFT	4931506343	4058546556570
0079 37	1	SHAFT	4931506344	4058546556587